




Ladder Shelf




A × 1




B × 1




C × 1




D × 1




E × 1




F × 2




G × 3



H × 3




① 9+2




② 12+2




③ 3+1




④ x 6




⑤ x 2




⑥ x 1




⑦ x 2




⑧ x 3




Tools Required:








1





× 3





2





3






4




5



6




OR



7		× 2
---	---	-----



WARNING



EN

- Children have died from furniture tipover.
- ALWAYS secure furniture with an anchoring device.
- NEVER allow children to stand, climb, or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.
- NEVER place a TV on this furniture.