






Instruction




Lounge Chaise

Product List

<p>Part A</p>  <p>Lounge Chaise</p> <p>1PC</p>	<p>Part B</p>  <p>Backrest Pillow</p> <p>1PCS</p>	<p>Part C</p>  <p>Throw Pillow</p> <p>2PCS</p>	<p>Part D</p>  <p>Unpacking Tool</p> <p>1PC</p>
---	--	--	--

Operation Guide


Step 1



Use a box cutter or scissors to carefully open the outer cardboard box. Avoid cutting too deeply to prevent damaging the contents inside.


Step 2

Tear off it




Carefully peel off the sealing tape from the package. Then, unwrap and remove the outer winding film that secures the product.

Step 3



Use the Part D unpacking tool to open the compressed vacuum film. Be careful not to scratch the fabric.

Step 4



Place the sofa in a well-ventilated area and allow it to expand to their original shape. This process may take 72 hours. Avoid sitting on them during this period.