
SAFETY WARNING

1. This bed is designed for use only mattress (es) meeting the following specifications on the upper bunk, and lower bunk:

Up/Lower bed (Bunk bed and tribed included)


Bed type	Length	Width	Thickness
Twin Standard	74"-75"	38" 1/2"	6" max
Full Standard	74"-75"	53"/54"	6"/ 7"

2. Replacement parts, including additional guardrails, maybe obtained from IFurniture,Inc.
3. Follow the information on the warnings appearing on the upper bunk bed end structure and on the carton. Do not remove warning label from bed.
4. Always use the recommended size mattresses or mattress supports, or both, to help prevent the likelihood of entrapment or falls.
5. Surface of mattress must be at least 5" (127mm) below the upper edge of guardrails.
6. Do not allow children under 6 years of age to use the upper bunk.
7. Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.
8. Do not allow horseplay on or under the bed and prohibit jumping on the bed.
9. Always use the ladder for entering and leaving the upper bunk.
10. Do not use substitute part. Contact the manufacture or dealer for replacement part.
11. Use of a night light may provide added safety precaution for a child using the upper bunk.
12. Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.
13. The use of water or sleep flotation mattresses is prohibited.
14. STRANGULATION HAZARD - Never attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hook, belts and jump ropes.
15. Keep these instruction for future reference.






Assembly Instructions
816 - 014

Part in Box



Hardware List

1.	JCBC M6 x 90mm 	x 38
2.	JCBC-W M6 x 50mm 	x 10
3.	M6 x 13mm (Short) Barrel Nut 	x 16
4.	Wood Dowel M10 x 30mm 	x 32
5.	M6 x 15mm (Long) Barrel Nut 	x 22
6.	CSK M4 x 25mm 	x 44
7.	Metal Pin M10 x 100mm 	x 4
8.	JCBC-W M6 x 30mm 	x 8
9.	JCBC M6 x 30mm 	x 18
10.	Ladder Hook 	x 2
11.	Sticker Cap 	x 4

12.	JCBC M6 x 10mm 	x 2
13.	CSK M4 x 16mm 	x 6
14.	Adjustable Screw 	x 3
15.	M8 Flat Washer 	x 3
16.	JCBB M8 x 80mm 	x 3
17.	M4 Allen Key 	x 1
18.	M5 Allen Key 	x 1

⚠ WARNING !!

- This package contains small parts. Keep away from children until assembly.
- Adult assembly required.
- Phillips head screw driver required.
- Instructions are generic. Figures may vary.
- Screws left after assembly should be kept out of reach of children.

NOTE : Children under the age of 9 should not use the upper bunk due to the statistical chance of significant injury.

- Children should be discouraged from playing on the bunk bed.
- The bunk bed should be checked periodically to ensure that the guardrail,ladder and other components are maintained in the correct position and state of repair and all connectors are tight.
- ' The upper bunk must be more than 2m from any ceiling fan.'

Tool required for assembly :

* Allen Key (supplied)
* Phillips Screwdriver (not supplied)

1 Assemble the Upper Bunk End Frames.


1.	JCBC M6 x 90mm		x 8
3.	M6 x 13mm (Short) Barrel Nut		x 8
4.	Wood Dowel M10 x 30mm		x 8

2 Assemble the Upper Bunk End Frames with the Side Rails(G1)(G2) and Front &Back Guard Rails (I&H). Attach Spindle (J).

1.	JCBC M6 x 90mm	x 14
4.	Wood Dowel M10 x 30mm	x 4
5.	M6 x 15mm (Long) Barrel Nut	x 14
9.	JCBC M6 x 30mm	x 12


3 Assemble the Slats (N) to the Upper Bunk.

8.	CSK Screw M4 x 25mm	x 22
10.	JCBC-W M6 x 30mm	x 4




4 Assemble the Lower Bunk End Frames.

1.	JCBC M6 x 90mm	x 8
3.	M6 x 13mm (Short) Barrel Nut	x 8
4.	Wood Dowel M10 x 30mm	x 8



5 Assemble the Lower Bunk End Frames with the Side Rails(G).

1.	JCBC M6 x 90mm	x 8
4.	Wood Dowel M10 x 30mm	x 4
5.	M6 x 15mm (Long) Barrel Nut	x 8
7.	Metal Pin M10 x 100mm	x 4
9.	JCBC M6 x 30mm	x 2
12.	JCBC M6 x 10mm	x 2




6 Lock the Support Legs (O) on Slats (Q) & Center Rail (K).

Please Note that the Hex Nut or Support Legs (O) have Adjuster at Bottom.Unscrew to Adjust if nesessary.


Assemble the Slats (Q) to the Lower Bunk.

6.	CSK Screw M4 x 25mm	x 22
8.	JCBC-W M6 x 30mm	x 4
14.	Adjustable Screw	x 3
15.	Flat Washer	x 3
16.	JCBC M8 x 80mm	x 3




7 Join the Upper & Lower Bunk.

9.	JCBC M6 x 30mm	x 4
11.	Sticker Cap	x 4




8 Assemble the Ladder (L,L1&M).

2.	JCBC-W M6 x 50mm	x 8
4.	Wood Dowel M10 x 30mm	x 8
10.	Ladder Hook	x 2
13.	Csk Screw M4 x 16mm	x 4



10 Attach the Ladder to the Upper Bunk.

2.	JCBC M6 x 50mm		x 2
13.	CSK M4 x 16mm		x 2

