ASSEMBLY INSTRUCTION

1



2



Ax1	Bx1	Cx4	Dx4	Ex1