ASSEMBLY INSTRUCTION

1



2



3



4



Ax1	Bx2 
Cx1 	Dx1 
Ex4  M6x37mm	Fx8  M6x25mm
Gx4 M6x20mm	Hx16
Ix12	Jx4
Kx1 	Lx1