


HARDWARE PACKED LIST IN BOX

| | 18.11 17 | | • | D-11 | | | | | | | | |
|------------|-----------------------------|----------|------------|-------|--------------|----------|----------------------------|-------|---|---------------|-------------|----------|
| (a) | Allen Key ø5/16° | 1PCS | (b) | Bolt | 12PCS | © | Bolt <i>∞</i> 1/4"*1.5" | 16PCS | | Flat Washe | er ∅1/4" | 16 16 |
| | | | | | | | | | | | | |
| e | Spring Washe ø5/16" ø1/4" | 16 16 | (f) | | 0 PCS | 9 | NUT ∅5/16" | 4PCS | h | Rails plastic | sla | 26PCS |
| | | | | | | | | | | | | |
| <u>(i)</u> | Center plastic slat | 13PCS | Wrench | 1 | Not provided | \odot | Allen Key ø1/4" | 1PCS | k | Bolt | 2" | 4PCS |
| | | | | \Im | | | | | | V////// | | |


QUEEN BED ASSEMBLY INSTRUCTIONS

ITEM:1826Q

STEP 1 Fasten (J) to bottom of footboard (H) with screw(c).




STEP 2 Bolts to use for side rails, should already come pre-inserted on the HB. Place bolt (b) , washers (e , d) and fasten to Headboard with preinstalled hardware, Repeat step 2 for Footboard. Do not tighten until step 3.




STEP 3

Attach siderail (E) to headboard (G) and footboard (H) using bolt (b) and allen key (a) as shown in diagram. Do not tighten bolts completely until assembly is completed.




STEP 4

Attach center support (F) to headboard (G) by using bolt (b) through washers (e, d) as shown in diagram.




STEP 5


Attach leg support (K) to center support bar (F) by using bolt (k), washers(e , d), nut (g), and tight the nut(g) by wrench.



STEP 6 Insert center plastic slot (i) into holes on center support bar (F). Press firmly into place as shown in diagram. Attach rail plastic slat (h) using same procedure.



STEP 7 Insert small slat (I) into plastic slats (h, i) as shown in diagram. Attach long slat (L) to Siderail (E) with bolt f as shown.



STEP 8 Assembly is complete.

