




QUEEN BED  
ASSEMBLY INSTRUCTIONS










ITEM:1821Q

BOX LIST

E	SideRail	2PCS	H	Footboard	1PCS
F	Center Support bar	1PC	I	Small Slat	24PCS
			J	Feet	2PCS
			P	Metal Leg Support	2PCS
			L	LONG SLAT	1PCS



HARDWARE PACKED LIST IN BOX

Allen Key			Bolt					Flat Washer		
a	ø5/16"	1PCS	b	ø5/16"*1.5"	12PCS	c		d	ø5/16"	16PCS
										
Spring Washe			Bolt			NUT			Rails plastic sla	
e	ø5/16"	16PCS	f	ø1/4"*1"	0 PCS	g	ø5/16"	4PCS	h	26PCS
										
Center plastic slat			Wrench			Allen Key			Bolt	
i		13PCS		Not provided		j	5mm	k	ø5/16"*2"	4PCS
										


MADE IN CHINA

**QUEEN BED  
ASSEMBLY INSTRUCTIONS**

**ITEM: 1821Q**


**STEP1**

Bolts to use for side rails, should already come pre-inserted on the HB. Place bolt ( b ) , washers ( e , d ) and fasten to Headboard with preinstalled hardware, Repeat step 2 for Footboard. Do not tighten until step 3.




**MADE IN CHINA**


**STEP 2**  
Attach siderail (E) to headboard (G) and footboard (H) using bolt ( b ) and allen key ( a ) as shown in diagram. Do not tighten bolts completely until assembly is completed.




**STEP 3**  
Attach center support (F) to headboard (G) by using bolt ( b ) through washers( e , d ) as shown in diagram.




**STEP 4**  
Attach leg support (K) to center support bar (F) by using bolt ( k ), washers( e , d ), nut ( g ), and tighten the nut( g ) by wrench.



**STEP 5**  
Insert center plastic slot ( i ) into holes on center support bar (F). Press firmly into place as shown in diagram. Attach rail plastic slat ( h ) using same procedure.



**STEP 6**  
Insert small slat ( l ) into plastic slats ( h , i ) as shown in diagram. Attach long slat (L) to Siderail (E) with bolt f as shown.



**STEP 7**  
Assembly is complete.

