


ASSEMBLY INSTRUCTIONS

ITEM#: HY7509/HY7525/HY7593

Important Safety Instructions:


- Please read all instructions before beginning assembly
- Please make sure receive all the parcels to start the assembly
- For your safety and convenience, assembly by two people is recommended
- Use the parts and hardware lists to identify and separate each of the components included
- Save all packing materials until assembly is completed to avoid the accidental discarding of smaller parts or hardware




THANK YOU FOR PURCHASING

PARTS LIST
















1 X1	2 X2	3 X1	4 X1	5 X1
6 X1	7 X1	8 X1	9 X1	10 X2
11 X2	12 X4	13 X2	14 X1	15 X1
16 X1	17 X1	18 X1		















Maximum weight capacities




HARDWARE LIST

Name	Part	Qty.	Spare
A		34	1
B		34	1
C		42	1
D		2	
E		3	
F	 14"	1	
G	 14"	1	
H	 14"	1	
I	 14"	1	
J	 7/8" Bolt	3	1
K		4	
L		4	
M		6	1
N		1	
O		1	


Name	Part	Qty.	Spare
P	 1-3/8" Bolt	4	1
Q	 2" Screw	4	1
R	 1-1/2" Screw	4	
S	 9/16" Screw	4	1
T	 5/8" Screw	8	
U1		1	
U2		1	
U3		1	
U4		1	
V	 1/2" Screw	4	1
W	 1/2" Screw	12	3
X	 3/4" Nail	27	2

STEP 1


D x 2pcs



S x 4pcs








W x 6pcs




H x 1pc

I x 1pc





STEP 2

V x 4pcs




R x 4pcs




STEP 3

A x 4pcs




C x 12pcs










Ø8 x 30

W x 6pcs







G x 1pc

F x 1pc





STEP 4

B x 4pcs




Raw edge




STEP 5

A x 12pcs 




C x 12pcs 
Ø8 x 30

L x 4pcs 






STEP 6

B x 4pcs




STEP 7

B x 4pcs





STEP 8

Q x 4pcs



B x 4pcs







STEP 9


X x 27pcs



NO Screw




Safety glasses



STEP 10

A x 10pcs 





STEP 11

It is very important to add a small drop of glue to the connecting hole of the wooden stick!


A x 8pcs 

C x 18pcs 
Ø8 x 30



O 



x 2



x 4




STEP 12



B x 4pcs



O



It is very important to add a small drop of glue to the connecting hole of the wooden stick!






STEP 13

B x 4pcs





O




STEP 14

B x 10pcs




STEP 15

P x 4pcs





M x 4pcs



N




With assistant carefully
stand unit up.




STEP 16

K x 4pcs





T x 8pcs




WARNING

Caution, Storing electronic equipment may result in equipment overheating. Shelves located behind doors are not intended for storing electronic equipment. Placing electronic equipment in this area may result in equipment overheating




STEP 17


Installation




1




2




3



4




Adjustment






STEP 18

E x 3pcs



J x 3pcs



STEP 19


-Move unit to final location.

-Adjust drawer fronts as shown below.




Step1--Loosen screws on back of drawer front brackets as shown.

Step2--Position drawer front as required.


Step3--Tighten screws while holding drawer front in position.




DRAWER FRONT VIEW




STEP 1.






STEP 2.




STEP 3.



STEP 20



STEP 21



1. Position bookcase in final resting spot. Using 10mm bit to drill holes on the wall distance between the hole & top panel is 25mm.
2. Use supplied wall anchor and push/hammer into pilot hole until flush with wall. Refer to diagram 2
3. Reposition bookcase and use U1 screws to tighten Anti-tip belt onto wall. Refer to diagram 3.

